

Marketing – User Guide - Web, Mobile, Print  
(Courtesy of DIRECTV and AT&T)

# Your HD On-Screen Guide

## Channels

Highlight the channel abbreviation to get the channel description.

## TV Window

Watch your program while using the Guide.

## Highlight Bar

Use the **ARROW** buttons to highlight a program and view the program's description. To tune to a highlighted program, press **SELECT**.



## Advance Timeline

Press the **GREEN** button to advance 12 hours.  
Press the **RED** button to go back 12 hours.

## Guide Options

Press the **YELLOW** button to sort programming by category, move to specific date and time, change favorites list and see ON DEMAND titles.

## Timeline

To see what's on later, navigate forward with the **RIGHT ARROW**.  
Use the **LEFT ARROW** to go back.

Need **more info?** **TUNE TO CHANNEL 1**, DIRECTV's Customer Information Channel, and watch easy-to-follow instructional videos.

**Marketing – User Guide - Web, Mobile, Print (CONT.)**  
 (Courtesy of DIRECTV and AT&T)

# Enjoy Free Interactive Features

## Mix Channels<sup>1</sup>

Watch eight different news or sports broadcasts at the same time. Highlight a channel and press **SELECT** to tune directly to that channel.

**Channel 352** – News Mix / **Channel 205** – Sports Mix

This feature is currently not available to customers who have DIRECTV en Español programming packages.



## DIRECTV Active<sup>®</sup>

Get five-day local weather forecasts, lottery results, special offers and even horoscopes. Simply press **ACTIVE** on your remote to view the DIRECTV Active channel.



## ScoreGuide™

Get sports scores instantly without changing your channel or missing a big play. Press the **RED** button on your remote to see scores. Select **WATCH NOW** to switch to a game in progress.

To access ScoreGuide, you must be watching a national or regional sports network or one of the channels in the 700 range used for sports subscriptions (NFL SUNDAY TICKET™, NBA LEAGUE PASS, NHL® CENTER ICE® etc.).



**Marketing – User Guide - Web, Mobile, Print (CONT.)**  
(Courtesy of DIRECTV and AT&T)

# Get to Know Your DVR

## Record from the Program Guide

Press the **RECORD** button on your remote to record the show.  
Press it twice to record the entire season.

## 30-Second Slip

Press the **ADVANCE** button to skip ahead 30 seconds while watching a recorded program.

- ▶ Press once to fast-forward 30 seconds
- ▶ Hold it down to jump to the end of the selected program



## Organize Your Playlist

Press **LIST** on your remote, then press the **YELLOW** button and choose from the following options:

- ▶ Delete multiple programs at the same time
- ▶ Sort programs by category
- ▶ Change the order of your Playlist

## DIRECTV® DVR Scheduler<sup>2</sup>

Never miss your favorites again. Set your DVR from anywhere at any time.

- ▶ REGISTER – Go to [directv.com/register](http://directv.com/register)
- ▶ CONNECT – Download the free app for your Smartphone or tablet at [directv.com/mobileapps](http://directv.com/mobileapps). Or go to [directv.com/tvlistings](http://directv.com/tvlistings) from your computer.
- ▶ RECORD – Search for your show, then select to record it.



**Marketing – User Guide - Web, Mobile, Print (CONT.)**  
(Courtesy of DIRECTV and AT&T)

## ...and Your HD DVR

### Extend the recording time of a live broadcast

- ▶ Set recording of a future live broadcast from the Program Guide
- ▶ Select **ADD THIS EXTENSION** when prompted on-screen to extend the recording time
- ▶ The default setting extends the recording by 30 minutes — you can modify the extension time to be from one minute to three hours

### DoublePlay™

Two big games on at the same time?  
No worries, watch them both.

- ▶ While watching one game, press the **▼ DOWN ARROW** on your remote
- ▶ Press the **▼ DOWN ARROW** again to select a game on a different channel
- ▶ Use the **▼ DOWN ARROW** to toggle between the two games
- ▶ Pause or rewind either game so you don't miss any action



### QuickTune

Create a personal guide for quick access to your favorite channels.

- ▶ Tune to a favorite channel and press the **▲ UP ARROW** on your remote
- ▶ Use the arrow keys to select the first square you want to fill, and then press the **● GREEN** button
- ▶ Tune to eight other favorite channels and repeat
- ▶ Press the **▲ UP ARROW** whenever you want to access QuickTune

